


# Quote predisposizione allacci idraulici per lavabi su mensole Hoja plus

Seguire lo schema e le tabelle sotto riportate, per ricavare le quote corrette degli allacci idraulici mediante formula indicata



Tutte le quote, sia quelle riportate che quelle da ricavare, fanno riferimento ad un'altezza del piano lavabo di **900 mm** da terra

Per ricavare le quote corrette degli allacci idraulici (**B e C**) effettuare le seguenti formule:

**B = A** ( quota riportata in tabella ) - **80 mm**

**C = A** ( quota riportata in tabella ) - **160 mm**

**Esempio :**

Lavabo scelto : **B6R54**  
Quota **A** in tabella = 760 mm

( **A** 760 mm - **80 mm** ) = **B** 680 mm  
( **A** 760 mm - **160 mm** ) = **C** 600 mm

codice	A	codice	A
B6R81	780	B6R53	740
B6R65	780	B6R51	780
B6R63	760	B6R54	760
B6O65	740	LAT50	760
B6O60	740	B6T48	740
B6O62	740	B6T45	740
TFO60	740	B6Q45	740
TFO61	740	B6Q42	760
B6R60	740	B6Q43	740
LT061	760	B6T42	740
GE045	750	LAT41	760
GE044	750	B6Q38	740
B6O54	740	B6T37	740
B6O50	740	TE035	760
B6R56	740	B6T30	740

**A** = Altezza d'installazione della mensola **Hoja plus**  
( riportato nelle tabelle a fianco per ogni lavabo disponibile )


**B** = Carico acqua per rubinetteria su piano  
( ricavabile mediante formula )

**C** = Scarico acqua  
( ricavabile mediante formula )

# Modulo d'ordine mensole Hoja plus

Data \_\_\_\_\_ Cliente/Codice cliente \_\_\_\_\_ Vs. Riferimento \_\_\_\_\_  
 Ordine nr. \_\_\_\_\_ Codice mensola \_\_\_\_\_ Codice lavabo \_\_\_\_\_

## Dimensioni mensola




**A** \_\_\_\_\_  
**B** \_\_\_\_\_  
**C** \_\_\_\_\_

## Quote minime B - C per articolo

codice	B	C
B6R81	450	450
B6R65	350	350
B6R63	350	350
B6O65	365	365
B6O60	350	350
B6O62	340	340
TFO60	340	340
TFO61	340	340
B6R60	350	350
LT061	350	350
GE045	350	350
GE044	350	350
B6O54	350	350
B6O50	320	320
B6R56	340	340

codice	B	C
B6R53	310	310
B6R51	300	300
B6R54	315	315
LAT50	280	280
B6T48	290	290
B6T45	255	255
B6Q45	260	260
B6Q42	255	255
B6Q43	250	250
B6T42	250	250
LAT41	250	250
B6Q38	225	225
B6T37	225	225
TE035	225	225
B6T30	225	225

## Lavabi consigliati



## Informazioni supplementari

### Foro lavabo

Descrizione	Quantità
Foro per lavabo <input type="checkbox"/> Si <input type="checkbox"/> No	_____

### Foro rubinetto

Descrizione	Quantità
Foro rubinetto <input type="checkbox"/> Si <input type="checkbox"/> No	_____


Staffe di fissaggio incluse, disponibili come ricambio cod. FI018 a pag.320

Timbro e firma

# Shelves Hoja plus

## Dimensions of hydraulic connections for top mounted washbasins

Follow the diagram and the tables below, to get the correct dimensions of the hydraulic connections using the formula indicated



All shares, both reported and to be derived, refer to a height of **900 mm** washbasin top from the ground.

To get the correct price of the hydraulic connections (**B** and **C**), carry out the following formulae:

$$B = A \text{ (dimension shown in table) } - 80 \text{ mm}$$

$$C = A \text{ (dimension shown in table) } - 160 \text{ mm}$$

**Example :**

Washbasin chosen : **B6R54**  
Dimension **A** in table = 760 mm

$$(A \text{ 760 mm} - 80 \text{ mm}) = B \text{ 680 mm}$$

$$(A \text{ 760 mm} - 160 \text{ mm}) = C \text{ 600 mm}$$


**A** = Installation height of the Hoja plus shelf (shown in the tables next to each washbasin available)

**B** = Water load for top taps (obtained by formula)

**C** = Water drain (obtained by formula)

code	A	code	A
B6R810	780	B6R53	740
B6R650	780	B6R510	780
B6R63	760	B6R54	760
B6O65	740	LAT50	760
B6O60	740	B6T48	740
B6O62	740	B6T45	740
TFO60	740	B6Q45	740
TFO61	740	B6Q42	760
B6R60	740	B6Q43	740
LT061	760	B6T42	740
GE045	750	LAT41	760
GE044	750	B6Q38	740
B6O54	740	B6T37	740
B6O50	740	TE035	760
B6R56	740	B6T30	740

## Recommended washbasins





# Shelves Hoja plus

## Order form

Date \_\_\_\_\_ Customer / Customer number \_\_\_\_\_ Reference no. \_\_\_\_\_  
 Order number \_\_\_\_\_ Shelf code \_\_\_\_\_ Washbasin code \_\_\_\_\_

### Shelf size



**A** \_\_\_\_\_  
**B** \_\_\_\_\_  
**C** \_\_\_\_\_

### Minimum instalments B - C per article

code	B	C
B6R810	450	450
B6R650	350	350
B6R63	350	350
B6O65	365	365
B6O60	350	350
B6O62	340	340
TFO60	340	340
TFO61	340	340
B6R60	350	350
LT061	350	350
GE045	350	350
GE044	350	350
B6O54	350	350
B6O50	320	320
B6R56	340	340

code	B	C
B6R53	310	310
B6R510	300	300
B6R54	315	315
LAT50	280	280
B6T48	290	290
B6T45	255	255
B6Q45	260	260
B6Q42	255	255
B6Q43	250	250
B6T42	250	250
LAT41	250	250
B6Q38	225	225
B6T37	225	225
TE035	225	225
B6T30	225	225

### Additional information

#### Sink hole

Description	Amount
Sink hole <input type="checkbox"/> Si <input type="checkbox"/> No	_____

#### Tap hole

Description	Amount
Tap hole <input type="checkbox"/> Si <input type="checkbox"/> No	_____

Mounting brackets included, available as spare code FI018 on page 171

Stamp and signature \_\_\_\_\_